



## TALON™ Anti-slip Tapes Application Instructions

---



**DO test the adhesion to the surface before full installation commences.**



**DO allow TALON™ Anti-slip Tapes to come up to room temperature before use if stored below 10 degrees Celsius.**



**DO NOT apply TALON™ Anti-slip Tapes when the surface temperature is below 10 degrees Celsius.**

1. Always apply TALON™ Anti-slip Tapes and Treads to clean, dry and relatively smooth surfaces. Dusty, soiled or greasy surfaces should be thoroughly cleaned and allowed to completely dry before application.
2. Floor primer will enhance adhesion, particularly when used to seal porous concrete floors.
3. Simply brush primer on clean and dry surfaces and allow to dry before applying tape. Primer dries quite quickly in dry / warm environments but may take a little longer with varying conditions.
4. Primer dries with a light yellow / brown tinge, so we recommend masking off visible areas for a professional finish.
5. Use of a rubber seam roller will help to apply pressure and increase the bond.
6. A small bead of edge sealer can be used around the edges of your installation to prevent water ingress.
7. TALON™ Anti-slip Tapes and Treads can be walked on immediately and full bond will be achieved within 24 hours.
8. We DO NOT recommend the use of TALON™ Anti-slip Tapes and Treads on external wooden decking or similar structures. The presence of water that penetrates this type of product will damage the adhesive and lift the tape, even when applied in what seems to be dry conditions.
9. Please see our specifically designed decking strips for this type of project.
10. For patterned or diamond tread / chequered surfaces, all the above applies, but we would recommend the selection of our Conformable Tapes & Treads.

---

These application notes are for general guidance only.  
Please test the product to assess its suitability for the intended application before full installation.